

MELAG



beauty

SteriHero

My autoclave. My **superpower**.

 The autoclave is intended for use in foot care, cosmetics, piercing, tattoo and non-medical applications. It is not a medical device according to 93/42/EEC or EU 2017/745 (MDR).

Your new **superpower**

No matter what big tasks the day holds in store for you, **SteriHero Beauty** has your back. That's because the brand new stand-alone autoclave was designed specifically for cosmetic practices, salons and studios: From the features to the price! Trendsetting technologies, an incredibly advanced display and the unique MELAG quality - made in Germany give you the superpower to change everything:



Supersafe

Safety for your patients and clients: Class B autoclaves with the fractional vacuum process provide the safest sterilization of all wrapped and unwrapped instruments - regardless of their type and complexity.

Steam sterilization compliant with EN 13060

Superstrong

More than enough power for whatever you plan to do: High loading capacities, fast cycle times starting at 15 min, and an effective vacuum drying guarantee that your instruments will be ready for use again very quickly.

Up to 5 kg on 5 trays



Supersmart

The intuitive user interface with a large Smart-Touch display makes everything easier: From program selection to documentation. With the help of process monitoring, you can provide complete proof of a successful sterilization.

Documentation via USB or network*

Superrobust

An autoclave should never fail: We make no compromises when it comes to reliability and develop under the highest quality requirements at our headquarters in Berlin.

100 % quality - made in Germany



Protects the environment. And your patients.

SteriHero Beauty combines environmental protection with economic efficiency. Thanks to the groundbreaking stand-alone concept, Power Save energy-saving mode and a durable and robust design, our autoclaves are the best solution - for your budget and the environment.

* Power Save as of 01.07.2023 (Update can be performed independently by practice team)

*Network capability as of 01.07.2023 (Update can be performed independently by practice team)

Facts and figures at a glance.

SteriHero Beauty guarantees safe sterilization according to your needs with a wide range of programs.

Programs	Beauty-B	Quick-S	Quick-B	Gentle-B	Prion-B
Program specification	134 °C, holding time: 5.5 min	134 °C, holding time: 3.5 min	134 °C, holding time: 5.5 min	121 °C, holding time: 20.5 min	134 °C, holding time: 20.5 min
Operating times (at minimum to maximum load) *	22 – 27 min	15 – 18 min	22 – 25 min	37 – 42 min	37 – 42 min
Drying (time controlled)	20 min	5 min	10 min	20 min	20 min

* Times for Type-B programs for single wrapped load and Quick-S for unpacked load. Times may vary depending on the type and quantity of load.

Order no.	Device type	Chamber size	Chamber volume	Load quantity	Device dimensions (W x H x D)	Weight	Power supply	Documentation interfaces
ME10118B	Stand-alone Klasse B Autoklav (Compatible with additional water treatment unit)	ø 25 cm x 35 cm long	17 litres	5 kg instruments / 1,8 kg textiles	47 x 50 x 64 cm (device fits on a 60 cm table top)	48 kg	220 – 230 V / 50 – 60 Hz (2100 Watts)	USB, network (Network capability from 01.07.2023)

i The autoclave is intended for use in foot care, cosmetics, piercing, tattoo and non-medical applications. It is not a medical device according to 93/42/EEC or EU 2017/745 (MDR).

The dream team for instrument reprocessing

The MELAG system solution makes your vision of a time-, space- and cost-saving hygiene workflow come true: Contact us to arrange your individual consultation to find out more about the perfect interplay of the MELAG thermal disinfectors, sealing devices, autoclaves and software solutions.



On site at your practice



Via online live demo



At the MELAG showroom

Rev.0-23/0719-03.23-EN-ME



Save paper, protect the environment:

In order to reduce paper, we provide you with electronic user documentation via our Download Center. Further information www.melag.com

MELAG
competence in hygiene